— INSTRUCTION SHEET —



Application

The AE Techron T1000 Magnetic-Field Susceptibility Transformer was designed to exceed the AF Magnetic Field susceptibility test requirements of DO 160 Section 19 and Boeing D6-16050-5 Section 7.2

It may also be used as 10-to-1 step-down transformer for output currents of up to 100 A_{RMS}.

Description

The T1000 transformer provides up to 300 A-m and is able to generate up to 100A_{RMS}. The turns ratio provides a ten-to-one step down to the secondary winding.

The T1000 provides convenient input connectors via binding posts. Standard 0.75-inch spacing of binding posts allows use of standard plugs. Output is via 150A feed-through terminal block connectors. The connectors accept up to 1/0 AWG wire.

T1000 Transformer

AETECHRON

for Magnetic-Field Susceptibility Testing

Features

- Up to 100 ARMS secondary current
- Exceeds AF Magnetic Field test requirements of DO 160 Section 19 and Boeing D6-16050-5 Section 7.2
- Circuit breaker protected from over-current
- Durable steel and high-density polyethylene case for impact resistance

A 12-amp circuit breaker protects the unit against over-current conditions. A rugged, impact-resistant case and robust design protects the transformer from accidental damage.

The T1000 transformer is for use by experienced staff.

Unit Setup

Safety First

Throughout these instructions, special emphasis is placed on good safety practices. The LIGHTNING FLASH and EXCLAIMATION POINT graphics are used to highlight certain topics that require extra precaution.

Watch for These Symbols:



The lightning flash with the arrowhead symbol within an equilateral triangle is intended to alert the user to the presence of "danger-

T1000 Transformer Instructions

page 1 AETECHRON Information subject to change. www.aetechron.com

97-8002536 - 6-20-2023

ous voltage" inside the product that may constitute a risk of electric shock.



The exclamation point within an equilateral triangle is intended to alert the user to the presence

of important operating and maintenance instructions in the literature accompanying the product.

Important Safety Instructions

- 1. Read and keep these instructions. Follow all instructions and heed all warnings.

2. Do not use this apparatus near water. To reduce the risk of fire or electric shock. do not expose this apparatus to rain or moisture. Do not expose this equipment to dripping or splashing and ensure that no objects filled with liquids, such as vases, are placed on the equipment.



Disconnect this product from all 3. sources of electrical power before cleaning. Use a damp cloth for cleaning. Clean the outside of the product only.

- Care should be taken so that ob-4. jects do not fall into the product.
- 5. Do not block any ventilation openings. Install in accordance with the manufacturer's instructions.
- Do not install near any heat sources 6. such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.
- Only use attachments/accessories 7. specified by the manufacturer.



Refer all servicing to gualified service personnel. Servicing is required when the apparatus has been damaged in any way, such as liquid has been spilled or objects have fallen into the apparatus, the apparatus

has been exposed to rain or moisture, does not operate normally, or has been dropped.

- 9. Do not remove product covers. No user serviceable parts inside. Refer servicing to qualified service personnel.
- 10. Always use the appropriate wire size and insulator for maximum voltage and current expected.
- 11. Operating conditions: 10°C to 40°C; Humidity: 70% or less, non-condensing.


Unpacking

Carefully unpack and inspect the unit. Please note any damage for future reference and notify the shipping company immediately if damage is found. Also, please save the shipping carton and materials as evidence of damage and/or for returning the unit for repair.

Connecting the T1000 Transformer (see Figure 1)

- Before connecting the T1000, make 1. sure all equipment you are connecting is disconnected from AC power.
- 2. Connect from a power amplifier, another power source, or a simulated load to your equipment under test.
- 3. Connect from a power amplifier to the T1000 4-way binding post input connectors. Connection can be made with cables terminated with spade lugs, banana plugs, pin connectors or bare wire.
- Create a cable using AWG 3 to 4. 1/0 wire. Connect from the T1000 output connectors to the radiating wire loop.

Equipment Maintenance



T1000 Transformer Instructions page 2 97-8002536 - 6-20-2023 AETECHRON




Figure 1 – DO 160 Section 19 Test Load Wiring

user serviceable parts inside. Internal fuses should only be replaced by a service technician. Refer all servicing to qualified service personnel.

Disconnect this product before cleaning. Use a damp cloth for cleaning. Clean the outside of the product only.

Factory Service

If the unit fails to perform, it may need to be returned for Factory Service. All units under warranty will be serviced free of charge (customer is responsible for oneway shipping charges as well as any custom fees, duties, and/or taxes). Please review the Warranty included with this Instruction Sheet for more information.

All service units must be given Return Authorization by AE Techron, Inc. before being returned. Return Authorizations can be requested on our website or by contacting our Customer Service Department.

Please take extra care when packaging your unit for repair. It should be returned in its original packaging or a suitable alternative. Replacement packaging materials can be purchased for a nominal fee. Please send all service units to the following address and be sure to include your Return Authorization Number on the box.

AE Techron, Inc. Attn: Service Department / RMA# 2507 Warren Street Elkhart, IN 46516

Specifications

Performance Specifications

Primary: 200 V_P maximum input

Secondary: 20.0 V_P maximum output

Dielectric Test: 1200 VDC

Turns Ratio: Ten-to-one step down

Protection: Input power-protected via circuit breaker

Controls and Connectors (see Figure 2)

Input Terminals: 4-way binding posts

T1000 Transformer Instructions

page 3

97-8002536 - 6-20-2023

AETECHRON

Information subject to change. www.aetechron.com




Figure 2 – T1000 Controls and Connectors

Output Terminals:

Feed-through terminal block (150A)

Circuit Breaker:

Primary input limited to 12A via circuit breaker; push to reset

Physical Characteristics

Case:

Steel interior shell with a durable external shell made from high-density polyethylene for impact resistance.

Operating Conditions,

Temperature: 10°C to 40°C (50°F to 104°F) **Humidity:** 70% or less, non-condensing

Recommended Ambient Temperature: 25°C (77°F)

Cooling: Natural air convection

Weight: 15 lbs. (6.8 kg)

Dimensions (HxWxD):

9.75 in. x 5.25 in. x 10.375 in. (24.8 cm x 13.3 cm x 26.4 cm)

Additional Product Information

This manual does not include all of the details of design, production, or variations of the equipment. Nor does it cover every possible situation which may arise during installation, operation or maintenance.

Additional information may be included with your unit via digital media and is also available at the AE Techron website at www.aetechron.com.

T1000 Transformer Instructions

page 4 **AETECHRON** Information subject to change. www.aetechron.com




Figure 3 – T1000 Maximum SOA (safe operating area)

Information Accuracy

The information provided in this manual was deemed accurate as of the publication date. However, updates to this information may have occurred. To obtain the latest information for your unit, please visit the AE Techron website at www. aetechron.com.

Trademark Notice

AE Techron is a registered trademark of AE Techron, Inc. Other trademarks are the property of their respective owners.

page 5 **AETECHRON**

Three-Year, No-Fault Warranty

SUMMARY OF WARRANTY

AE TECHRON INC., of Elkhart, Indiana (Warrantor) warrants to you, the ORIGI-NAL COMMERCIAL PURCHASER and ANY SUBSEQUENT OWNER of each NEW **AE TECHRON INC.** product, for a period of three (3) years from the date of purchase, by the original purchaser (warranty period) that the product is free of defects in materials and workmanship and will meet or exceed all advertised specifications for such a product. We further warrant the new AE Techron product regardless of the reason for failure, except as excluded in the Warranty.

ITEMS EXCLUDED FROM WARRANTY

This AE Techron Warranty is in effect only for failure of a new AE Techron product which occurred within the Warranty Period. It does not cover any product which has been damaged because of any intentional misuse, or loss which is covered under any of your insurance contracts. This warranty does not extend to any product on which the serial number has been defaced, altered, or removed. It does not cover damage to loads or any other products or accessories resulting from **AE TECHRON INC.** product failure. It does not cover defects or damage caused by the use of unauthorized modifications, accessories, parts, or service.

WHAT WE WILL DO

We will remedy any defect, regardless of the reason for failure (except as excluded), by repair or replacement, at our sole discretion. Warranty work can only be performed at our authorized service centers or at our factory.

Expenses in remedying the defect will be borne by **AE TECHRON INC.**, including one-way surface freight shipping costs within the United States. (Purchaser must bear the expense of shipping the product between any foreign country and the port of entry in the United States and all taxes, duties, and other customs fees for such foreign shipments.

HOW TO OBTAIN WARRANTY SERVICE

When you notify us of your need for warranty service, we will give you an authorization to return the product for service. All components must be shipped in a factory pack or equivalent which, if needed, may be obtained from us for a nominal charge. We will take corrective actions within a reasonable time of the date of receipt of the defective product. If the repairs made by us are not satisfactory, notify us immediately.

T1000 Transformer Instructions 97-8002536 - 6-20-2023

page 6 **AETECHRON** Information subject to change. www.aetechron.com

DISCLAIMER OF CONSEQUENTIAL AND INCIDENTAL DAMAGES

You are not entitled to recover from us any consequential or incidental damages resulting from any defect in our product. This includes any damage to another product or products resulting from such a defect.

WARRANTY ALTERATIONS

No person has the authority to enlarge, amend, or modify this warranty. The warranty is not extended by the length of time for which you are deprived of the use of this product. Repairs and replacement parts provided under the terms of this warranty shall carry only the unexpired portion of this warranty.

DESIGN CHANGES

We reserve the right to change the design of any product from time to time without notice and with no obligation to make corresponding changes in products previously manufactured.

LEGAL REMEDIES OF PURCHASER

There is no warranty that extends beyond the terms hereof. This written warranty is given in lieu of any oral or implied warranties not contained herein. We disclaim all implied warranties, including, without limitation, any warranties of merchantability or fitness for a particular purpose. No action to enforce this Warranty shall be commenced later than ninety (90) days after expiration of the warranty period. This statement of warranty supersedes any others contained in this manual for AE Techron products.

AE Techron, Inc.

Customer Service Department 2507 Warren Street Elkhart, IN 46516 U.S.A. 574.295.9495 www.aetechron.com

page 7

AETECHRON

Information subject to change. www.aetechron.com